


Esploso 60706 KWU7502-50L



Parts List					
NO	Name	Quinty	NO	Name	Quinty
1	Crankcase	4	34	Air filter	2
2	Wire fasten ring	2	35	Air pipe	2
3	Shrinkable tube	2	36	Bolt	4
4	Ground wire screw	2	37	Fasten part	4
5	Spring washer	8	38	Exhaust valve sheet	4
6	Bolt	8	39	Intake valve sheet	4
7	Stator	2	40	Metal cushion	4
8	Rotor	2	41	Bolt	4
9	Bearing	4	42	Cylinder head bracket	4
10	Shock relief foot pad	8	43	Bolt	4
11	Nut	8	44	2# Air compressor head	1
12	Nut	8	45	High pressure soft tube	2
13	Bearing	4	46	Check valve	2
14	Bolt	8	47	Magnetic valve	2
15	Crank	4	48	Axle	2
16	Fan	4	49	Wheel	2
17	Locking-ring	4	50	Nut	2
18	Fan cover	4	51	Tank	1
19	Bolt	8	52	Capacitor	2
20	Connect rod	4	53	Capacitor cover	2
21	Piston ring	4	54	Terminal cap	7
22	Fasten plate	4	55	Nut	2
23	Bolt	4	56	Foot pad	2
24	Cylinder	4	57	Bolt	2
25	O'-ring	4	58	Dain valve	1
26	Valve plate	4	59	Handle grip	1
27	Cylinder cover seal ring	4	60	Pressure switch	1
28	Cylinder cover	4	61	Pressure gauge	2
29	Exhaust elbow	2	62	Safety valve	1
30	Plain washers	16	63	Ball valve	2
31	Bolt	16	64	Regulator valve	1
32	O'-ring	8	65	Lead wire	1
33	Connect pipe	4	66	Power cord	1