


Exploding diagram for HYV8T-550E



Spare parts list for HYV8T-55E

| No. | Spare parts | QTY | Remark |
|-----|----------------------------------|-----|----------------------------|
| 1 | Switch(KOA7) | 1 | 230V/50Hz/IP54 |
| 2 | Motor 230V/50Hz/3.0KW | 1 | |
| 3 | Gear pump 2.1ml/r | 1 | |
| 4 | Hexagonal socket screw | 2 | |
| 5 | Oil inlet hose | 1 | |
| 6 | Oil filter | 1 | |
| 7 | Oil dipstick | 1 | |
| 8 | “O”-ring 14*2.4 | 1 | |
| 9 | Direction exchanging valve | 1 | Assembly |
| 10 | Hexagonal bolt M12*20 | 1 | |
| 11 | Seal ring M12 | 1 | (beneath the bottom of oil |
| 12 | Main column body | 1 | Welded assembly |
| 13 | Axle for wheel | 1 | |
| 14 | Clip | 4 | |
| 15 | Oil outlet hose | 1 | |
| 16 | Cotter pin | 2 | |
| 17 | Wheel ϕ 200 | 2 | |
| 18 | Connection shaft | 1 | |
| 19 | Stop ϕ 24 | 2 | |
| 20 | Hexagonal bolt M10*25 | 4 | |
| 21 | Nut | 2 | |
| 22 | Knob | 2 | ABS+Q235A |
| 23 | Working table | 1 | Welded assembly |
| 24 | Right operation handle and guard | 1 | Assembly |
| 25 | Right storage | 1 | Welded assembly |
| 26 | Nut | 12 | |
| 27 | Square neck bolt M8*100 | 4 | |
| 28 | Round plastic cover | 1 | ABS |
| 29 | Plastic supporting board(front) | 1 | PA6 |
| 30 | Plastic supporting board(back) | 1 | PA6 |

| No. | Spareparts | QTY | Remark |
|------------|---------------------------------|------------|-----------------|
| 31 | Plastic supporting board(left) | 1 | PA6 |
| 32 | Plastic supporting board(right) | 1 | PA6 |
| 33 | Left operation handle and guard | 1 | Assembly |
| 34 | Left storage | 1 | Welded assembly |
| 35 | Splitting wedge | 1 | Welded assembly |
| 36 | Top cover | 1 | ABS |
| 37 | Knob M6 | 1 | ABS+Q235A |
| 38 | Fixing board | 4 | PA6 |
| 39 | Restricting pole | 1 | |
| 40 | Connection tube | 1 | Welded assembly |
| 41 | Connection board | 1 | |
| 42 | Hexagonal bolt M8*25 | 1 | |
| 43 | Hexagonal socket screw M20*65 | 1 | |
| 44 | Nut M20 | 1 | |
| 45 | Cylinder | 1 | Assembly |
| 36 | Hydraulic oil hose 1 | 1 | |
| 47 | Hydraulic oil hose 2 | 1 | |

RICAMBI DISPONIBILI

Legenda esploso 85950 / HYV8T-550E

| Parte nr. | Codice | Descrizione (ITA) | Description (ENG) | EAN |
|--------------|--------------|--------------------------|----------------------------|---------------|
| 1 | 95951 | Interruttore accensione | Switch | 8028815959513 |
| 2 | 95952 | Motore | Motor | 8028815959520 |
| 3-4 | 95953 | Pompa ad ingranaggi | Gear pump | 8028815959537 |
| 5-6-15-46-47 | 95954 | Tubi e filtro olio (kit) | Oil hoses and filter (kit) | 8028815959544 |
| 9 | 95955 | Valvola di scambio | Direction exchanging valve | 8028815959551 |
| 13-16-17 | 95956 | Ruote e asse (kit) | Wheels and axle | 8028815959568 |
| 45 | 95957 | Cilindro olio | Cylinder | 8028815959575 |
| n/a | 95958 | Guarnizioni (kit) | Gaskets | 8028815959582 |